



MOUNTING INSTRUCTION

1

MOTOR APEX

Double-check the motor and gearbox size.
Clean the mounting surface.

2

APEX

Remove the plug on the adapter plate.
Rotate the set collar till the bolt is line up.

3

MOTOR

a. Remove motor key.
b. Insert balance key.

4

APEX

Check motor shaft size and
insert bushing if necessary.

Correct installation.
When installing on **flatted shafts**,
be sure to align the collet gap over
the flat and the set collar bolt
perpendicular to the flat.

5

MOTOR APEX

Set at vertical position. Tighten the mounting bolts
(including washer) in 1~4 order with wrench to 5%
specified torque. (See Table 1)

6

Tighten the set collar bolt with torque
wrench to specified torque. (See Table 2)

7

MOTOR

Tighten the mounting bolts in 1~4 order with
torque wrench to specified torque. (See Table 1)

8

Tighten back the screw plug.

Table 1 Tightening Torque Recommended for Motor Mounting Bolt

Bolt Size	Width Across Flats	Strength 8.8 Tightening Torque		Strength 10.9 Tightening Torque		Strength 12.9 Tightening Torque	
	[mm]	[Nm]	[In-lbs]	[Nm]	[In-lbs]	[Nm]	[In-lbs]
M3 x 0.5P	2.5	1.3	12	1.8	16	2.1	19
M4 x 0.7P	3	3	27	4.1	37	4.9	44
M5 x 0.8P	4	6.1	55	8.2	73	9.8	87
M6 x 1P	5	11	98	14	124	17	151
M8 x 1.25P	6	25	222	34	302	41	364
M10 x 1.5P	8	49	434	67	594	80	709
M12 x 1.75P	10	85	753	116	1028	139	1232
M14 x 2P	12	137	1214	186	1648	223	1976
M16 x 2P	14	210	1860	286	2534	343	3038

Table 2 Tightening Torque Recommended for Set Collar Bolt

Gearbox Size		Motor Shaft Dia.	Bolt Size	Width Across Flats	Tightening Torque	
					[mm]	[mm]
AB042 AF042 AE050 AFX042	1 stage	≤ 11	M3 x 0.5P x 8L	2.5	2.1	19
	2 stage	≤ 11	M3 x 0.5P x 8L	2.5	2.1	19
AB060 AF060 AE070 AFX060 AN023 AN023B	1 stage	≤ 14	M4 x 0.7P x 12L	3	4.9	44
	2 stage	≤ 11	M3 x 0.5P x 8L	2.5	2.1	19
AB090 AF075 AE090 AFX075 AN034 AN034B	1 stage	≤ 19	M5 x 0.8P x 14L	4	9.8	87
	2 stage	≤ 14	M4 x 0.7P x 12L	3	4.9	44
AB115 AF100 AE120 AFX100	1 stage	≤ 32	M6 x 1P x 16L	5	17	151
	2 stage	≤ 19	M5 x 0.8P x 14L	4	9.8	87
AB142 AF140 AE155 AFX140	1 stage	≤ 38	M8 x 1.25P x 20L	6	41	364
	2 stage	≤ 32	M6 x 1P x 16L	5	17	151
AB180 AF180 AE205 AFX180	1 stage	≤ 48	M10 x 1.5P x 25L	8	80	709
	2 stage	≤ 38	M8 x 1.25P x 20L	6	41	364
AB220 AF220 AE235	1 stage	≤ 55	M12 x 1.75P x 30L	10	139	1232
	2 stage	≤ 48	M10 x 1.5P x 25L	8	80	709
AB060A AF060A AFX060A AN023A AN023C	2 stage	≤ 14	M4 x 0.7P x 12L	3	4.9	44
AB090A AF075A AFX075A AN034A AN034C	2 stage	≤ 19	M5 x 0.8P x 14L	4	9.8	87
AB115A AF100A AFX100A	2 stage	≤ 32	M6 x 1P x 16L	5	17	151
AB142A AF140A AFX140A	2 stage	≤ 38	M8 x 1.25P x 20L	6	41	364

Note: Holding torques must be bigger than values shown above. Bolts can be tightened up to 20% higher for increased holding torques.



APEX DYNAMICS, INC.

Tel : +886-4-24650219 / Fax : +886-4-24650118

E-Mail : sales@apexdyna.com / Web : www.apexdyna.com

NO.10.Keyuan.3rd.Rd.Situn District.Taichung City.407.Taiwan(R.O.C)